



PR500 Series

The PR500 Mask-Mounted PAPR has been favored by workers for its comfort and by companies for its cost-effectiveness. This combination has made it a popular choice for contractors and various manufacturing applications.

INDUSTRIES & APPLICATIONS

- Abatement and Remediation (asbestos, Mold)
- Lead Reclamation
- Hazardous Particulates
- Nuclear/Utilities
- Military Maintenance
- Pulp/Paper

*See "caution and limitations" on the approval sheet included with your product



UNIQUELY DESIGNED FOR YOUR ENVIRONMENT

- Lightweight, compact full facepiece.
- Sealed, water-resistant contoured battery is worn comfortably with the decontamination belt along the waist, eliminating the worry of the battery falling out of pockets, or tearing a propylene suit.
- Replaceable power cord extends the life of your investment.
- 5-point facepiece harness provides improved fit.

Product Number	Product Description	Mask Size	Case Qty.	Case Weight	Case Dimensions
PR501S	PR500 Mask-Mounted PAPR Kit includes Facepiece with 5-Point Headstrap, battery, cable, blower, shower cap and battery charger	Small	1 Kit	4.4 lbs	13"L x 9"W x 5.5"H
PR501M		Medium	1 Kit	4.4 lbs	13"L x 9"W x 5.5"H
PR501L		Large	1 Kit	4.4 lbs	13"L x 9"W x 5.5"H
108044	High Efficiency Particulate Air-Purifying (HEPA) filter	-	84 Filters/Case	18.7 lbs	22.7"L x 11.6"W x 14.9"H

TECHNICAL SPECIFICATIONS

- Battery Life: 8 hours
- Battery Type: NiCad, Rechargeable
- Blower delivers air at a flow rate greater than 115 liters per minute (4 cubic feet per minute)

APPROVALS & STANDARDS

- NIOSH approved
- HE Protection
- Assigned Protection Factor (APF) 1,000
- Meets OSHA Respiratory Protection Standard 29 CFR 1910.134

For more information visit www.prestigeameritech.com/papr

Prestige Ameritech
 7201 Iron Horse Blvd.
 North Richland Hills, TX 76180
 (817) 427-2700
www.prestigeameritech.com

